



1- Apply a strip of Teflon tape around threading of the shower arm.

2- Hand screw the diverter valve (A) by only turning the end cap.

3- Connect the shower head to the extremity of the valve.

4- Connect the shower hose (B) to the bottom exit of the valve.

5- At the end of the hose, connect the small valve and then connect the enema shower (C) to the small valve.

6- Make sure the rubber washers are in place in each connection.